

# BOLTING GUIDELINES

To achieve a trouble-free joint, one of the most important aspects to consider is the bolts or studs. Reliability depends on achieving and maintaining an acceptable level of tension in each bolt. The target tension level for most applications can be calculated using the KLINGER Expert gasket analysis software.

However, the method employed to tighten the bolts is very important and can result in significant variations from those anticipated. As a guide, the following table shows the variation of bolt tension per the tightening method.

Method Used	Tools Required	Variation of tension from mean value
Wrench (No Torque Control)	Spanner or Wrench	±50%
Wrench (With Torque Control)	Calibrated Torque Wrench	±30%
Hydraulic Tensioner	Multiple Stud Tensioners	±10% to ±30%
Direct Strain Measurement	Rotabolt pre-set Studs	±5%

If the initial bolt stress is too low, the total amount of strain (stretch in the bolt) is likewise low and under these circumstances any subsequent reduction in thickness of the gasket due to creep will quickly result in loss of bolt strain and subsequent leakage.

Within reason, it is best practice to generate a significantly adequate bolt stress based on the material of construction and any recommendations from the manufacturer. This is often achieved at 50-70% of the yield strength at the operating temperature.

Other points to consider are:

- » The crushing strength of the gasket
- » The hydrostatic end thrust will increase the bolt tension at the operating internal pressure
- » Using a bolt stress which represents less than 50% of the yield strength will cause problems and should only be considered under certain circumstances
- » Most flanges are tightened with ordinary wrenching methods and it is often advantageous to have design bolt stresses which require no more than this; the probable bolt stress developed manually is often expressed as:

$$S_b = \frac{1560}{\sqrt{d_b}} N/mm^2$$

Where:  $S_b$  = bolt stress achieved on assembly  
 $d_b$  = bolt diameter in mm

**KLINGER Thermoseal**

2350 Campbell Road, Sidney, Ohio 45365  
 Tel: +1 937 498 2222

3803 S. Sam Houston Parkway W., Houston, Texas 77053  
 Tel: +1 713 997 8111

For smaller bolts, this results in excessive stress unless care is exercised. For larger bolts, however, it is often impossible to develop the required stress by hand.

REMINDER: As the temperature increases, the yield strength of the bolt material decreases.

*The ability of a gasket to make and maintain a seal depends not only on the style and quality of the gasket material, but also on medium being sealed, the flange design, the amount of pressure applied to the gasket by the bolts and how the gasket is assembled onto the flanges and tightened. These factors are beyond the manufacturer's control.*

**KLINGER Thermoseal**

2350 Campbell Road, Sidney, Ohio 45365

Tel: +1 937 498 2222

3803 S. Sam Houston Parkway W., Houston, Texas 77053

Tel: +1 713 997 8111